

OWNER'S MANUAL


MODEL NO.: 8000

VKR OPTION


REF. NO.: WMT-VKR

ASSEMBLY INSTRUCTION MANUAL 8000-VKR

HARDWARE ILLUSTRATIONS



HEX HEAD BOLT




SOCKET HEAD
SCREW



LOCKNUT



FLAT
WASHER




HARDWARE PARTS LIST


NO.	QTY	PART NAME	WHERE USED
A	9	3/8" x 3-1/4" (82MM) LONG HEX HEAD BOLT	
C1	4	3/8" x 2-1/2" (65MM) LONG HEX HEAD BOLT	
G	2	3/8" x 3/4" (25MM) SHORT HEX HEAD BOLT	
H	3	8MMx25MM	
J	9	3/8" NYLON LOCKNUT	
N	24	3/8" FLAT WASHER	
O	3	8MM FLAT WASHER	

PARTS LIST


NO.	QTY	ART NAME	USE	FIG	BOX (CONTENT)			
					1	2	3	4
1	4	RUBBER FEET CAPS		1			4	
5s	1	VKR BASE SUPPORT		1			1	
25	3	7" CHROME TUBE HANDLES		3			3	
26	3	RUBBER HANDLES (SMALL)		3			3	
26a	2	RUBBER HANDLES (LARGE)		3			2	
27	2	NYLON CAPS WITH HOLES		3			2	
32m	1	VKR UPRIGHT SUPPORT		2		1		
33s	2	GUIDE ROD TOP MOUNTS VKR		2			2	
48	1	VKR		3			1	
49	1	15"x8"x2" BACK PAD		3			1	
50	2	15"x5"x2" ARM PAD		3			2	
63	2	2" SQUARE NYLON PLUGS		2			2	




MMT-VKR FIGURE 1



MMT-VKR FIGURE 2



MMT-VKR FIGURE 3



MMT-VKR FIGURE 4