


MAINTENANCE

Folding/unfolding


About MI150:

Before folding, please have the incline value to 0 level.



Fold up:


After the workout session you can fold the treadmill to the upright position for space saving. When it reaches top position, it goes to lock and there is a click sound for locking.




Release to unfold:

Pull out the lock knob on the right side of frame and then lower the treadmill.

FOLD-UP




1. LIFT THE TREADMILL




1. PUSH UP FRAME
2. PULL OUT KNOB FOR LOCKING

FOLD-DOWN (RELEASE)



1. PULL DOWN FRAME
2. PULL OUT KNOB FOR RELEASING



1. LOWER THE TREADMILL
WITH HAND SUPPORT

Horizontal Adjustment

To fit machine on floor stable, you can adjust the 2 screws located under the front of base frame.

1. Lift the machine on one side and then turn the screw under the front of base frame.
2. Turn the screw clockwise to make the screw up.
3. Turn the screw counterclockwise to make the screw down.

