

NOTE:

Please read all
instructions carefully
before using this product



MARCY®
By IMPEX

CIRCUIT II HOME GYM

Table of Contents

Safety Notice

Hardware Identifier

Assembly Instruction

Weight Resistance
Chart

Parts List

Warranty


Ordering Parts

**Model
Circuit II**

**Retain This
Manual for
Reference**

Sep. 11, 1998

**OWNER'S
MANUAL**



IMPEX INC.

14777 Don Julian Rd., City of Industry, CA 91746
(800) 999-8899 Fax (626) 961-9966

TABLE OF CONTENTS

BEFORE YOU BEGIN.....	1
IMPORTANT SAFETY NOTICE.....	2
HARDWARE IDENTIFIER.....	3
ASSEMBLY INSTRUCTIONS.....	4
WEIGHT RESISTANCE CHART.....	18
PARTS LIST.....	19
WARRANTY.....	20
ORDERING PARTS.....	20

BEFORE YOU BEGIN

Thank you for selecting the **CIRCUIT II HOME GYM** by **IMPEX FITNESS PRODUCTS**. For your safety and benefit, read this manual carefully before using the machine. As a manufacturer, we are committed to provide you complete customer satisfaction. If you have any questions, or find there are missing or damaged parts, we guarantee you complete satisfaction through direct assistance from our factory. To avoid unnecessary delays, *please call our TOLL-FREE customer service number*. Our Customer Service Agents will provide immediate assistance to you.

Toll-Free Customer Service Number
1-800-999-8899
Mon. - Fri., 9 a.m. - 5 p.m. PST

IMPORTANT SAFETY NOTICE

PRECAUTIONS

This exercise machine is built for optimum safety. However, certain precautions apply whenever you operate a piece of exercise equipment. Be sure to read the entire manual before you assemble or operate your machine. In particular, note the following safety precautions:

1. **Keep children and pets away from the machine at all times. DO NOT leave children unattended in the same room with the machine.**
2. Only one person at a time should use the machine.
3. If the user experiences dizziness, nausea, chest pain, or any other abnormal symptoms, **STOP** the workout at once. **CONSULT A PHYSICIAN IMMEDIATELY.**
4. Position the machine on a clear, leveled surface. **DO NOT** use the machine near water or outdoors.
5. Keep hands away from all moving parts.
6. Always wear appropriate workout clothing when exercising. **DO NOT** wear robes or other clothing that could become caught in the machine. Running or aerobic shoes are also required when using the machine.
7. Use the machine only for its intended use as described in this manual. **DO NOT** use attachments not recommended by the manufacturer.
8. Do not place any sharp object around the machine.
9. Disabled person should not use the machine without a qualified person or physician in attendance.
10. Before using the machine to exercise, always do stretching exercises to properly warm up.
11. Never operate the machine if the machine is not functioning properly.

WARNING: BEFORE BEGINNING ANY EXERCISE PROGRAM, CONSULT YOUR PHYSICIAN. THIS IS ESPECIALLY IMPORTANT FOR INDIVIDUALS OVER THE AGE OF 35 OR PERSONS WITH PRE-EXISTING HEALTH PROBLEMS. READ ALL INSTRUCTIONS BEFORE USING ANY FITNESS EQUIPMENT. IMPEX INC. ASSUMES NO RESPONSIBILITY FOR PERSONAL INJURY OR PROPERTY DAMAGE SUSTAINED BY OR THROUGH THE USE OF THIS PRODUCT.

SAVE THESE INSTRUCTIONS.

HARDWARE IDENTIFIER

PLACE WASHER, END OF BOLT, OR SCREW
ON CIRCLE TO CHECK FOR CORRECT SIZE.

MILLIMETERS

M6



M8



M10



INCHES


1/2"



5/8"



3/4"



REPLACEMENT PARTS


Thank you for purchasing IMPEX product. Although we go to great effort to ensure the quality of our products, occasionally errors or omissions occur. Should you find either a defective or missing part in this product, please contact us for a replacement at the telephone number.

QUESTION ?




1-800-999-8899

NOTE: When installing a Aircraft Nut (also called Nylon or Lock Nut), Please use two adjustable wrenches to tighten down the Nut. Hold down the Bolt with one wrench, and use the other wrench to turn the Nut clockwise.



HEX HEAD BOLT



AIRCRAFT
NUT



FLAT
WASHER



ROUND
PLUG



SQUARE
PLUG

ASSEMBLY INSTRUCTION

Tools required to assembly the machine:

Two Adjustable Wrenches

Two Allen Wrenches

NOTE: It is strongly recommended that this machine be assembled by two or more people to avoid possible injury.


STEP 1 (SEE DIAGRAM 1)

- A.) Place the Base Frame (#1) firmly on the floor. Attach the Rear Stabilizer (#2) to the Base Frame. Attach the Rear Vertical Frame (#4) to the back of the Rear Stabilizer. Align the holes and secure it with two M10 x 3" Bolts (#65), four $\varnothing 7/8"$ Washers (#74), and two M10 Aircraft Nuts (#72). Note: Do not tighten all the nuts and bolts yet. Only finger-tighten them for now.
- B.) Attach the Front Vertical Frame (#5) to the Base Frame (#1). Align the holes and secure it with two M10 x 3" Bolts (#65), four $\varnothing 7/8"$ Washers (#74), and two M10 Aircraft Nuts (#72).
- C.) Attach the Upper Frame (#3) to the top of the Vertical Frames (#4 & 5). Secure the front with two M10 x 3" Bolts (#65), four $\varnothing 7/8"$ Washers (#74), and two M10 Aircraft Nuts (#72). Secure the back with one M10 x 2 1/2" Bolt (#66), one M10 x 3" Bolt (#65), three $\varnothing 7/8"$ Washers (#74), one 4"x2" Bracket (#30), and one M10 Aircraft Nut (#72).

STEP 2 (SEE DIAGRAM 2)

- A.) Attach the Right Base Frame (#8) and the Bottom Socket Assembly (#7) to the Base Frame (#1). Align the holes and secure it with two M10 x 3" Bolts (#65), four $\varnothing 7/8"$ Washers (#74), and two M10 Aircraft Nuts (#72).
- B.) Place a $\varnothing 1 \frac{1}{2}"$ Washer (#62) onto the axle on the Base Frame (#1). Attach the Lower Pulley Frame (#11) to the axle and secure it with a $\varnothing 7/8"$ Washer (#74), and M10 x 5/8" Bolt (#76).
- C.) Place two Rubber Bumpers (#43) onto the Bottom Socket Assembly (#7). Align the two holes and push two Weight Plate Guide Rods (#26) through the Bumpers into the base.
- D.) Slide nineteen Weight Plates (#79) from top of the Guide Rods (#26) down to the base. Note: The groove on the Plates should always face down and toward the left side of the machine. Insert the Selecting Rod (#31) into the center hole on the Plates. Slide the Selector Stem (#81) onto the Guide Rods. Align the hole and secure the Selector Stem (#81) to the Selecting Rod (#31) with a M10 x 1 1/2" Socket Bolt (#57).
- E.) Attach the Top Socket Assembly (#6) to the top of the Weight Plate Guide Rods (#26). Secure it to the Upper Frame (#3) with two M10 x 3" Bolts (#65), four $\varnothing 7/8"$ Washers (#74), one 4 3/4" x2" Bracket (#50), and two M10 Aircraft Nuts (#72). Secure the Top Socket Assembly (#6) to the Weight Plate Guide Rods (#26) with two M6 x 5/8" Bolts (#70).
- F.) Securely tighten all the nuts and bolts previously installed.

DIAGRAM 1



ASSEMBLY INSTRUCTION

Tools required to assembly the machine:

Two Adjustable Wrenches

Two Allen Wrenches

NOTE: It is strongly recommended that this machine be assembled by two or more people to avoid possible injury.

STEP 1 (SEE DIAGRAM 1)

- A.) Place the Base Frame (#1) firmly on the floor. Attach the Rear Stabilizer (#2) to the Base Frame. Attach the Rear Vertical Frame (#4) to the back of the Rear Stabilizer. Align the holes and secure it with two M10 x 3" Bolts (#65), four Ø7/8" Washers (#74), and two M10 Aircraft Nuts (#72). Note: Do not tighten all the nuts and bolts yet. Only finger-tighten them for now.
- B.) Attach the Front Vertical Frame (#5) to the Base Frame (#1). Align the holes and secure it with two M10 x 3" Bolts (#65), four Ø7/8" Washers (#74), and two M10 Aircraft Nuts (#72).
- C.) Attach the Upper Frame (#3) to the top of the Vertical Frames (#4 & 5). Secure the front with two M10 x 3" Bolts (#65), four Ø7/8" Washers (#74), and two M10 Aircraft Nuts (#72). Secure the back with one M10 x 2 ½" Bolt (#66), one M10 x 3" Bolt (#65), three Ø7/8" Washers (#74), one 4"x2" Bracket (#30), and one M10 Aircraft Nut (#72).

STEP 2 (SEE DIAGRAM 2)


- A.) Attach the Right Base Frame (#8) and the Bottom Socket Assembly (#7) to the Base Frame (#1). Align the holes and secure it with two M10 x 3" Bolts (#65), four Ø7/8" Washers (#74), and two M10 Aircraft Nuts (#72).
- B.) Place a Ø1 ½" Washer (#62) onto the axle on the Base Frame (#1). Attach the Lower Pulley Frame (#11) to the axle and secure it with a Ø7/8" Washer (#74), and M10 x 5/8" Bolt (#76).
- C.) Place two Rubber Bumpers (#43) onto the Bottom Socket Assembly (#7). Align the two holes and push two Weight Plate Guide Rods (#26) through the Bumpers into the base.
- D.) Slide nineteen Weight Plates (#79) from top of the Guide Rods (#26) down to the base. Note: The groove on the Plates should always face down and toward the left side of the machine. Insert the Selecting Rod (#31) into the center hole on the Plates. Slide the Selector Stem (#81) onto the Guide Rods. Align the hole and secure the Selector Stem (#81) to the Selecting Rod (#31) with a M10 x 1 ½" Socket Bolt (#57).
- E.) Attach the Top Socket Assembly (#6) to the top of the Weight Plate Guide Rods (#26). Secure it to the Upper Frame (#3) with two M10 x 3" Bolts (#65), four Ø7/8" Washers (#74), one 4 ¾" x2" Bracket (#50), and two M10 Aircraft Nuts (#72). Secure the Top Socket Assembly (#6) to the Weight Plate Guide Rods (#26) with two M6 x 5/8" Bolts (#70).
- F.) Securely tighten all the nuts and bolts previously installed.

STEP 3

(SEE DIAGRAM 3)

- A.) Attach the Butterfly Support (#21) and the Butterfly Pulley Frame (#22) to the Rear Vertical Frame (#4). Secure them with two M10 x 3" Bolts (#65), four $\varnothing 7/8"$ Washers (#74), and two M10 Aircraft Nuts (#72).
- B.) Place a Butterfly Cable Guide (#23) onto the axle on the Right Butterfly (#17). Insert the Right Butterfly through the hole on the Butterfly Support (#21). Secure it with a $\varnothing 1 \frac{1}{2}"$ Washer (#44), M12 Aircraft Nut (#71), and M12 Cone Shape Cap (#51).
- C.) Repeat the above step B to install the other Butterfly (#16).
- D.) Attach the Rear Main Seat Support (#10) to the Rear Vertical Frame (#4). Secure it with two M10 x 3" Bolts (#65), four $\varnothing 7/8"$ Washers (#74), one 4 $\frac{3}{4}"$ x 2" Bracket (#50), and two M10 Aircraft Nuts (#72).


DIAGRAM 3



STEP 4 (SEE DIAGRAM 4)


- A.) Attach a Butterfly Pad (#35) to the Right Butterfly (#17). Secure it with two $\varnothing 1/2"$ Washers (#75) and M8 x 2 1/2" Hex Bolts (#59). Repeat the same step for the other side.
- B.) Attach the Rear Backrest Pad (#38) to the Rear Vertical Frame (#4). Secure it with two $\varnothing 1/2"$ Washers (#75) and M8 x 2 1/2" Hex Bolts (#59).
- C.) Attach the Rear Seat (#39) to the Rear Seat Post (#9). Secure it with two $\varnothing 1/2"$ Washers (#75) and M8 x 2 1/2" Hex Bolts (#59). Insert the Seat Post through the opening on the Rear Main Seat Support (#10) and secure it with a Quick Release Pin (#46).
- D.) Attach the Arm Curl Pad (#41) to the Arm Curl Stand (#40). Secure it with two $\varnothing 1/2"$ Washers (#75) and M8 x 5/8" Hex Bolts (#60).
- E.) Attach the Arm Curl Stand to the opening on the Rear Main Seat Support (#10) and secure it with a Knob Bolt (#83).

DIAGRAM 4



STEP 5 (SEE DIAGRAM 5)


- A.) Attach the Front Press Base (#14) to the Upper Frame (#3). Insert a $\varnothing 5/8"$ x 8 5/8" Axle (#32) through the holes and secure it with two $\varnothing 7/8"$ Washers (#74) and M10 Aircraft Nuts (#72).
- B.) Attach the Front Press (#15) to the Front Press Base (#14). Attach six $\varnothing 1"$ Bushings (#55) to the openings. Insert a $\varnothing 1"$ x 12 3/8" Axle (#33) through the holes. Secure it with two $\varnothing 1 \frac{1}{2}"$ Washers (#44) and M12 x 1" Bolts (#69).
- C.) Lubricate the inside of the Foam Grips (#49) with water. Slide them onto the Front Press (#15).
- D.) Attach the Backrest Frame (#13) to the Front Vertical Frame (#5). Secure it with two M10 x 3" Bolts (#65), four $\varnothing 7/8"$ Washers (#74), one 4 3/4" x 2" Bracket (#50), and two M10 Aircraft Nuts (#72).
- E.) Attach the Front Main Seat Support (#18) to the Front Vertical Frame (#5). Secure it with two M10 x 3 3/4" Bolts (#64), four $\varnothing 7/8"$ Washers (#74), one 4 3/4" x 2" Bracket (#50), and two M10 Aircraft Nuts (#72).
- F.) Attach two $\varnothing 1/2"$ Bushings (#56) to the openings in the front of the Front Main Seat Support (#18). Attach the Leg Developer (#20) to the opening and secure it with a M12 x 3 1/4" Bolt (#63), two $\varnothing 1"$ Washers (#73), and one M12 Aircraft Nut (#71). Attach two M12 Cone Shaped Caps (#51) to both sides of the nut and bolt.



STEP 6 (SEE DIAGRAM 6)

- A.) Attach the Front Backrest Pad (#36) to the Backrest Adjustment Post (#12). Secure it with four $\varnothing 1/2"$ Washers (#75) and M8 x 5/8" Hex Bolts (#60). Attach the Post to the Backrest Frame (#13) and secure it with a Quick Release Pin (#46).
- B.) Attach the Lumbar Support Pad (#37) to the Front Vertical Frame (#5). Secure it with two $\varnothing 1/2"$ Washers (#75) and M8 x 3 1/4" Hex Bolts (#58).
- C.) Attach the Front Seat (#34) to the Front Seat Post (#19). Secure it with two $\varnothing 1/2"$ Washers (#75) and M8 x 2 1/2" Hex Bolts (#59). Attach the Post to the opening on the Front Main Seat Support (#18) and secure it with a Quick Release Pin (#46).
- D.) Insert a Foam Roll Tube (#27) halfway through the hole in front of the Seat. Push two Foam Rolls (#48) onto the Tube from both sides. Plug two Foam Roll End Caps (#61) to the ends of the Tube.
- E.) Repeat the above step D to install another set of Foam Rolls for the Leg Developer.


DIAGRAM 6



STEP 7 (SEE DIAGRAM 7)

- A.) Attach one end of the 82" Butterfly Cable (#82) to the Butterfly Cable Guide (#23). Secure it with one M10 x 1" Bolt (#68), two $\varnothing 7/8"$ Washers (#74), and one M10 Aircraft Nut (#72). Attach the other end of the Cable to the other Cable Guide.
- B.) Draw the Cable (#82) to the bracket underneath the Butterfly Pulley Frame (#22). Attach a Pulley (#52) and two Pulley Covers (#53) to the Cable. Align the hole on the Pulley to the bracket and secure it with one M10 x 1 $\frac{3}{4}"$ Bolt (#67), two $\varnothing 7/8"$ Washers (#74), and one M10 Aircraft Nut (#72). Repeat the same procedure to install the other side.
- C.) Pull the Cable downward and attach Pulley (#52) and two Pulley Covers (#53) in the mid-span. Attach a Single Floating Pulley Bracket (#29) to the Pulley and secure it with one M10 x 1 $\frac{3}{4}"$ Bolt (#67), two $\varnothing 7/8"$ Washers (#74), and one M10 Aircraft Nut (#72). Let the Floating Pulley Bracket hanging for now.

DIAGRAM 7



STEP 8 (SEE DIAGRAM 8)

- A.) Attach the 168 1/2" Upper Cable (#85) to the top of the Upper Frame (#3). Attach a Pulley (#52) and two Pulley Covers (#53) to the beginning of the Cable. Secure it to the top of the Upper Frame with one M10 x 2 1/2" Bolt (#66), two Ø7/8" Washers (#74), and one M10 Aircraft Nut (#72).
- B.) Draw the Cable over another Pulley set on top of the Upper Frame. Insert the Cable downward through the hole.
- C.) Draw the Cable to the Front Press Base (#14). Install another set of Pulley using one M10 x 7 7/8" Axle, two 1" Plastic Spacers, Ø7/8" Washers (#74), and M10 Aircraft Nuts (#72). Please note the Spacers should be installed on both sides of the Pulley, in between the Front Press Base.
- D.) Draw the Cable to the Front Vertical Frame (#5) and install another set of Pulley.
- E.) Draw the Cable back to the Front Press Base and install another set of Pulley following the above step C.
- F.) Draw the Cable back to and through the Front Vertical Frame (#5) and install another set of Pulley.
- G.) Attach another Pulley set and two Double Pulley Brackets (#89) to the Cable. Secure it with one M10 x 1 3/4" Bolt (#67), two Ø7/8" Washers (#74), and one M10 Aircraft Nut (#72).
- H.) Draw the Cable upward to the bracket underneath the Upper Frame. Install another set of Pulley.
- I.) Draw the Cable to the bracket underneath the Top Socket Assembly (#6). Install another set of Pulley. Pull the Cable downward towards the Selector Stem (#81). Screw the Bolt at the end of the Cable into the Stem by 1/2". Do not screw the Bolt all the way in the Stem. It may cause the cable to be too short.

STEP 9 (SEE DIAGRAM 9)

- A.) Insert the 86" AB Crunch Cable (#86) through the Front Vertical Frame (#5). Attach a Pulley (#52) to the Cable. (Note: There is no Pulley Cover needed.) Secure it with one M10 x 2 1/2" Bolt (#66), two Ø7/8" Washers (#74), two Ø3/8" Bushings (#77), and one M10 Aircraft Nut (#72).
- B.) Draw the Cable downward and install another set of Pulley. Secure it with two Double Pulley Brackets (#89), one M10 x 1 3/4" Bolt (#67), two Ø7/8" Washers (#74), and one M10 Aircraft Nut (#72).
- C.) Draw the Cable upward to the Pulley Bracket set previously installed in Step 8. Install another Pulley set.
- D.) Draw the Cable downward to install another Pulley set with two Pulley Brackets (#89).
- E.) Draw the Cable upward to the Single Floating Pulley Bracket (#29) previously installed in Step 7. Secure it with one M10 x 1" Bolt (#68), two Ø7/8" Washers (#74), and one M10 Aircraft Nut (#72).

DIAGRAM 8





DIAGRAM 9




STEP 11

(SEE DIAGRAM 11)

- A.) Attach the 95" Leg Developer Cable (#84) to the Lower Pulley Frame (#11). Install a Pulley set.
- B.) Draw the Cable upward to the bracket previously installed in Step 9. Install another Pulley set.
- C.) Draw the Cable downward to the bracket on top of the Base Frame (#1). Install another Pulley set.
- D.) Draw the Cable through the opening on the bottom of the Front Vertical Frame (#5). Install another Pulley set.
- E.) Attach one end of the Short Chain (#87) to the back of the Leg Developer (#20). Secure it with one M10 x 1" Bolt (#68), two $\varnothing 7/8"$ Washers (#74), and one M10 Aircraft Nut (#72).
- F.) Connect the other end of the Chain (#87) to the Cable with a Hook (#54).

DIAGRAM 11




STEP 12

(SEE DIAGRAM 12)

- A.) Attach two Weight Plate Covers (#28) to the outside of the Selective Weight Plates. Secure them with four $\varnothing 7/8"$ Washers (#74) and M10 x 1" Bolts (#68).
- B.) Attach a Short Chain (#87) to the Upper Cable with a Hook. Attach the Lat Bar (#24) to the Chain with a Hook.
- C.) Attach a Long Chain (#88) to the Leg Developer Cable with a Hook (#54). Attach the Shiver Bar (#25) to the Chain.

DIAGRAM 12



WEIGHT RESISTANCE CHART

This chart shows the approximate weight resistance at each station. The "Top" refers to the 10 lb. selector stem. The other numbers refer to the number of plates below the stem.

WEIGHT PLATES	FRONT PRESS (lbs.)	LEG CURL (lbs.)	HIGH PULLEY (lbs.)	LOW PULLEY (lbs.)	ARM CURL (lbs.)	BUTTER FLY (lbs.)
Top	10	10	10	10	10	2.5
1	20	20	20	20	20	5
2	30	30	30	30	30	7.5
3	40	40	40	40	40	10
4	50	50	50	50	50	12.5
5	60	60	60	60	60	15
6	70	70	70	70	70	17.5
7	80	80	80	80	80	20
8	90	90	90	90	90	22.5
9	100	100	100	100	100	25
10	110	110	110	110	110	27.5
11	120	120	120	120	120	30
12	130	130	130	130	130	32.5
13	140	140	140	140	140	35
14	150	150	150	150	150	37.5
15	160	160	160	160	160	40
16	170	170	170	170	170	42.5
17	180	180	180	180	180	45
18	190	190	190	190	190	47.5
19	200	200	200	200	200	50

- Weight resistance shown for the butterfly station is for each arm.
- Actual resistance may vary.

Part No.	Description	Q'ty		
1.	Base Frame	1		
2.	Rear Stabilizer	1	48. Foam Roll	4
3.	Upper Frame	1	49. Foam Grip	2
4.	Rear Vertical Frame	1	50. 4 3/4" x 2" Bracket	4
5.	Front Vertical Frame	1	51. M12 Cone Shaped Cap	4
6.	Top Socket Assembly	1	52. Pulley	24
7.	Bottom Socket Assembly	1	53. Pulley Cover	46
8.	Right Base Frame	1	54. Hook	8
9.	Rear Seat Post	1	55. Ø1" Bushing	14
10.	Rear Main Seat Support	1	56. Ø1/2" Bushing	2
11.	Lower Pulley Frame	1	57. M10 x 1 1/2" Socket Bolt	1
12.	Backrest Adjustment Post	1	58. M8 x 3 1/4" Hex Bolt	2
13.	Backrest Frame	1	59. M8 x 2 1/2" Hex Bolt	10
14.	Front Press Base	1	60. M8 x 5/8" Hex Bolt	6
15.	Front Press	1	61. Foam Roll End Cap	4
16.	Left Butterfly	1	62. Ø1 1/2" Washer	1
17.	Right Butterfly	1	63. M12 x 3 1/4" Bolt	1
18.	Front Main Seat Support	1	64. M10 x 3 3/4" Bolt	2
19.	Front Seat Post	1	65. M10 x 3" Bolt	17
20.	Leg Developer	1	66. M10 x 2 1/2" Bolt	9
21.	Butterfly Support	1	67. M10 x 1 3/4" Bolt	14
22.	Butterfly Pulley Frame	1	68. M10 x 1" Bolt	9
23.	Butterfly Cable Guide	2	69. M12 x 1" Bolt	2
24.	Lat Bar	1	70. M6 x 5/8" Bolt	2
25.	Shiver Bar	1	71. M12 Aircraft Nut	3
26.	Weight Plates Guide Rod	2	72. M10 Aircraft Nut	52
27.	Foam Roll Tube	2	73. Ø1" Washer	2
28.	Weight Plate Cover	2	74. Ø7/8" Washer	104
29.	Floating Pulley Bracket	1	75. Ø1/2" Washer	18
30.	4" x 2" Bracket	1	76. M10 x 5/8" Bolt	1
31.	Selecting Rod	1	77. Ø3/8" Bushing	2
32.	Ø5/8" x 8 5/8" Axle	1	78. M10 x 7 7/8" Axle	2
33.	Ø1" x 12 3/8" Axle	1	79. Weight Plates	19
34.	Front Seat	1	80. Top Plate	1
35.	Butterfly Pad	2	81. Selector Stem	1
36.	Front Backrest Pad	1	82. Butterfly Cable (82")	1
37.	Front Lumbar Support Pad	1	83. Knob Bolt	1
38.	Rear Backrest Pad	1	84. Leg Developer Cable (95")	1
39.	Rear Seat	1	85. Upper Cable (168 1/2")	1
40.	Arm Curl Stand	1	86. AB Crunch Cable (86")	1
41.	Arm Curl Pad	1	87. Short Chain	2
42.	1" Spacer	4	88. Long Chain	1
43.	Rubber Bumper	2	89. Double Pulley Bracket	6
44.	Ø1 1/2" Washer	4	90. AB Strap	1
45.	Arm Curl Cable (110")	1	91. Ankle Strap	1
46.	Quick Release Pin	3	92. Single Cross Pull Handle	1
47.	Selector Pin	1		